

Work Order ID 62753

Thursday, October 07, 2010 3:09:55 PM



Page 1

Item ID: D206-642-511

Accept



Setup Start



Revision ID:

Stop



Item Name: Float Skidtube LH

Start Date: 10/7/2010 Start Qty: 1.00



Cust Item ID:

Required Date: 10/15/2010 Req'd Qty: 1.00



Customer:

Reference:

Approvals:

Process Plan: *M*

Date: 10-10-07

Tooling:

Date:

Run Start



QC:

Date:

SPC (Y/N):

Date:

Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr
INN-D206-642	Rev M

100

0.00



DOCUMENT CONTROL

0.00

DC

Memo

Document Control

Photocopy bluefile and create labels per PPP D206-642-511CHG004

8 10/12/02

110

0.00



Pick Kit

0.00

Packaging

Memo

Packaging

10/12/02

120

0.00



QC4- 100% Inspect kits for completeness

0.00

QC

Memo

Quality Control

5 10/12/02

②

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 62753

Thursday, October 07, 2010 3:09:55 PM



Page 2

Item ID: D206-642-511

Accept



Setup Start



Revision ID:

Stop



Item Name: Float Skidtube LH

Start Date: 10/7/2010 Start Qty: 1.00



Cust Item ID:

Required Date: 10/15/2010 Req'd Qty: 1.00



Customer:

Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Run Start



QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130 Packaging Packaging	Packaging Memo Identify and pack for shipping as per PPP D206-642-511 Location: <u>73</u>	0.00 0.00							<u>10/12/03</u>
140 QC Quality Control	QC21- Final Inspection - Work Order Release Memo	0.00 0.00							<u>10/12/03</u> MF 10-12-02

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

Thursday, October 07, 2010 3:09:59 PM

Page 1

Work Order ID: 62753

Parent Item: D206-642-511

Parent Item Name: Float Skidtube LH

Start Date: 10/7/2010

Required Date: 10/15/2010

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP Rev:B 05.09.23 Revised per D206-642 Rev. J KJ/JLM
IPP Rev:C 07-02-23 As per IIN D206-642 Rev K JLM
IPP rev D 07.06.06 added K642-511 EC
IPP Rev:E 07-12-05 ECN 1080p Rev L DD verified by:

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D206-642-541

Manufactured

No

120

Each

1.0000

1

1



Replacement Skidtube



62753

Location

Loc Qty

Loc Code

FG073

1

34772

1

K642-511

Manufactured

No

120

Each

0.0000

1

1



saddle kit 642-511



63048

362765

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries